
## **CARVER - 9535**





# DIE BUILT-UP ALLOY WITH HIGH TENSILE STRENGTH

SMAW	FCAW	MCW	
DC+	DC+, 100% Co2 Or 75% Argon-25% CO2	DC+, 100% Co2 Or 75% Argon-25% Co2 Or 90% Argon- 10% CO2	

TECHNICAL DATA				
Alloy Type :	Nickel-Chromium- Molybdenum			
Tensile Strength :	850 N/mm²			
Elongation :	UP to 20%			
Machinability:	Good			
Hardness :	Rockwell C 35-38			
Available Processes :	SMAW, FCAW and MCW Wires			

### RECOMMENDED CURRENT RANGE

ELECTRODES				
SIZE (MM)	AMPS			
3.15	120-150			
4.00	160-190			
5.00	200-240			

FLUX CORED WIRES		METAL CORED WIRES	
SIZE (MM)	AMPS	SIZE (MM)	AMPS
1.6	270-320	1.6	270-320
2.4	330-370	2.4	330-370







# 330-370

## Registered Office:

### **CARVER ROBOWELD LIMITED**

1403, Space Odyssey, 150 Feet Ring Road, Nr. KKV Hall, Rajkot-360005 Gujarat-India Mobile: 97277 25540, 97277 25564

E: cwpl@carver.co.in · www.carverroboweld.com

### **FEATURES:**

For joining, buildup, and repairing cracked or fractured steels with up to 170,000 psi tensile strengths. CARVER 9535 has established itself as the standard for die block repair by exhibiting exceptional impact qualities, high tensile strength and good elongation. CARVER 9535 was designed to operate at high amperage for continuous out of position flood welding.

## **APPLICATIONS:**

Use for fabricating structures, machinery, assemblies and repair of equipment. Hot work applications include joining fractured forging dies that are to be machined. Expressly made for welding both wrought and cast steel structures. Also used for touch-up work and making engineering changes.

#### PROCEDURE:

Remove all defects; heat checks, spalls, and cracks. Preheat the unit to a minimum of 425°C. Maintain this temperature during welding. Utilize short arc length. Peening is necessary when filling in small cavities. Peen after depositing each pass. Peening is not necessary when welding large areas such as complete impressions except on the final pass. After welding cool the unit in still air to approximately 175°C. This is necessary to produce uniform weld hardness. When the cooling temperature is reached, immediately charge dies into a furnace at 560°C and temper for 12 to 16 hours. On rams, sow block and similar type units stress relieve at 620°C for 12 to 16 hours. Stress relieve hammer bases at 620°C at one hour per inch of thickness at temperature. Remove the unit from the furnace and cool in still air to room temperature.

Works:

Survey No. 98-P, Near GIDC Bamanbore Estate Phase-1, Taluka-Chotila, Bamanbore,

Rajkot-363 520 Gujarat-India.

Mobile: 97277 25555 · Email: cwco@carver.co.in